

RF300 – Help with Zone Alarm Firewall

Issue 2 – 03/01/2017

This help document refers to ZoneAlarm Pro Antivirus and Firewall

How do I allow the RF300 Diligence WiFi Sensor Software to communicate through my PC firewall?

Open ZoneAlarm Pro Antivirus and Firewall

1. In the Firewall tab, click **Settings** for the **Application Control** category.
2. Click **View Programs**.
3. Click **Add**.
4. Select **WiFi Sensor Software**.
5. Click **Open**.

How do I open the ports required by the RF300 Diligence WiFi Sensor Software?

Open ZoneAlarm Pro Antivirus and Firewall

1. Select **Firewall**.
2. In either the Trusted Zone or Public Zone area, click **Custom**. The Firewall settings dialog appears.
3. Scroll to the security level (High or Medium) to which you want to add ports.
4. Select the desired port type: incoming UDP, outgoing UDP, incoming TCP, or outgoing TCP.
5. You will need to unblock TCP port 10080 and UDP ports 1024 and 8010

Click **Apply**, then click **OK**.

End.