

# DT33

Digital Temperature Tester

# OPERATING INSTRUCTIONS



COMARK Instruments  
PO Box 500  
Beaverton, OR 97077  
Phone: 503-643-5204  
[WWW.COMARKUSA.COM](http://WWW.COMARKUSA.COM)

# Measuring Procedures

## Temperature Measurement

1. Depress the ON/OFF key on the DT33 to turn the instrument on.
2. Following Instructions for specific probe being used, proceed with temperature measurement.
3. To turn the DT33 off, depress the ON/OFF key.

## Battery Replacement

1. Remove four screws around perimeter of back casing and remove gently.
2. Replace 9V battery observing correct polarity.
3. Replace back casing and screws.

## **Returning for Repair**

Before returning your instrument for repair, make a quick check to ensure the failure is not due to a low or dead battery or defective probe.

CALL FOR AN RMA  
1-888-993-5853

## **Limited One Year Warranty**

This product is warranted to purchaser against defects in material and workmanship for one year from date of purchase.

What is covered: Repair parts and labor or replacement at the company's option.

What is not covered: Transportation to the company. Damages from abuse or improper maintenance, see operating instructions. Any other expense. Consequential damages, incidental damages, or incidental expenses, including damages to property.

## **Features of the DT33**

- Water Resistant
- Extended Temperature Range: -125°F to +500°F
- Interchangeable Probes
- One Year Limited Warranty
- 9V Battery included

## **Accessories**

J-Type Probes: ATT19, ATT27, ATT39, ATT40  
ATT41, ATT42, ATT54A

## **Specifications**

Range: -125°F to +500°F  
Accuracy: +0.1% of reading, +1.3°F