

RF300 – Help with McAfee All Access Software

Issue 2 – 03/01/2017

This help document refers to the McAfee All Access Software, although these instructions may also apply to other McAfee products.

How do I allow the RF300 Diligence WiFi Sensor Software to communicate through my PC firewall?

Open your McAfee application.

1. Click **Web and Email Protection**.
2. Click **Firewall**.
3. Click **Internet Connections for Programs** drawer.

NOTE: Depending on the version of the McAfee software you have installed, this may be called **Program Permissions**.

4. Scroll to the bottom and click **Add**.
5. Click **Browse** and locate the folder ..

C:\Program Files (x86)\WiFi Sensor Software

On some systems the folder may be .. **C:\Program Files\WiFi Sensor Software**

6. Select the program **WiFi Sensor Software.exe** and click **Open**.
7. Set the access type to **Full** in the **Access:** drop-down menu.
8. Click **Save**.

How do I open the ports required by the RF300 Diligence WiFi Sensor Software?

1. Open your McAfee Windows Security software.
2. Click **Web and Email Protection**.
3. Click **Firewall**.
4. Click **Ports and System Services**.
5. Click **Add**.
6. Enter the **WiFi Sensor Software** of the application with the System Service Name field. The exact name is unimportant. Scroll down.
7. In the **Local TCP/IP Ports:** field enter **10080**.
8. In the **Local UDP Ports:** field enter **1024, 8010**.
9. In the **Open ports to:** drop-down menu, select **All PCs**.
10. Click **Save**.

End.