



KM28 THERMOMETER

1. GETTING STARTED

Attach the probe to the instrument. Note that the connector is polarised with a "thin" pin and a "wide" pin, care needs to be taken to insert the probe the correct way.

To turn the instrument on/off press and release the on/off button on the left of the case.

2. AUTO OFF FEATURE

If you do not turn the instrument off manually it will switch off automatically after approximately 5/6 minutes.

3. SCALE SELECTION

Press the right hand button to change from °F to °C or vice versa. The scale is displayed in the top right hand of the window and is retained when switched off.

4. REPLACING THE BATTERY

Remove the battery cover by unscrewing the screw on the rear of the unit. Do this away from the food preparation area, taking care not to lose the screw.

The KM28 uses any standard 9 volt size battery and these are readily available. Alkaline versions are recommended for longest life.

Fit the battery and replace the cover. Take care not to overtighten the screw or to leave too loose.

5. ACCESSORIES

PK19M	Hypodermic needle probe
PK24M	Penetration probe
CRS/5	Boot

6. SPECIFICATION

Sensor Type	Thermocouple Type K
Measurement Range	-40 to 1000°F / -40 to 500°C
Resolution	0.1° up to approx 195, 1° above
Instrument Accuracy	±2°F / ±1°C
Ambient Temperature	32° to 122°F
Range	0° to 50°C
Battery	9V IEC 6LF22 standard/alkaline

WARNINGS

TO AVOID DAMAGE OR BURNS, DO NOT MAKE TEMPERATURE MEASUREMENTS IN MICROWAVE OR NORMAL OVENS.

DO NOT PLACE THE THERMOMETER IN A DISHWASHER AS IT IS NOT DISHWASHER SAFE.

DO NOT PLACE THE THERMOMETER IN A FRIDGE OR FREEZER AS DAMAGE MAY OCCUR DUE TO CONDENSATION FORMING WHEN THE INSTRUMENT IS REMOVED.

REGULAR CLEANING OF THE THERMOMETER AND PROBES IS RECOMMENDED USING A DAMP CLOTH AND NORMAL KITCHEN CLEANER. DO NOT USE ANY FORM OF SOLVENT.

THIS IS A PRECISION INSTRUMENT AND SHOULD BE TREATED WITH CARE IF LONG TERM PERFORMANCE IS TO BE ATTAINED.

Comark Instruments

PO Box 500,
Beaverton, OR 97077, USA
Tel: (503) 643 5204
Email: sales@comarkusa.com
www.comarkusa.com

Comark Instruments

52 Hurricane Way,
Norwich, Norfolk, NR6 6JB, UK
Tel: +44 (0) 207 942 0712
Email: sales@comarkinstruments.com
www.comarkinstruments.com