Calibration Procedure - KM820/V

Verifying Infra-Red Non contact thermometers

- Insert the reference thermometer probe (e.g. KM20Ref) fully into one of the holes in the Validator.
- Allow the instruments to stabilise to environment conditions
- Switch on both instruments after stabilisation period.
- Point the Infra-Red thermometer at the base of the Validator while ensuring the nozzle is as far inside the Validator cup as is possible. Note the variation. (acceptable error 2.5°C)

Verifying Contact Thermometers

- Insert the reference thermometer probe (e.g. KM20Ref) fully into one of the holes in the Validator.
- Insert the probe of the Instrument being verified fully into the other hole in the Validator.
- Allow the instruments to stabilise to environment conditions.
- Switch on both instruments after stabilisation period.
- Note the variation. The acceptance error will be dependent on the specification of the unit being verified

Note: The time for the instruments to stabilise will be dependent on the validator reaching its environment temperature, which at freezer temperatures could be up to 2 hours.



Care must be exercised when handling the validator after exposure to low temperatures.

Comark Instruments, 52 Hurricane Way, Norwich, Norfolk NR6 6JB United Kingdom

Telephone: +44 844 815 6599 Fax: +44 844 815 6598 E-mail: sales@comarkinstruments.com

Website: www.comarkinstruments.com

Stock No. 17064 Issue 6 (11/12)

© Comark Instruments

