

ATEX Pressure Meter- Cleaning Instructions

Issue 3 – 19/04/2020

Comark ATEX Pressure Meters – Cleaning Instructions

Dear Customers/Distributors

In this new reality where cleaning your instruments is more necessary than ever, especially if you are sharing them between colleagues, we felt it necessary to explain how you should clean your ATEX Pressure Meters to ensure that the special protective coating on the LCD Window is not removed.

Cleaning should only be carried out with a dry lint free cloth or one soaked in soapy water. At no time should your Pressure Meter be immersed into water, hot or cold, as this can cause damage to the delicate sensor arrangement.

Comark now provides a Lint Free Cloth with all Pressure Meters, for cleaning your Instrument.

Under no circumstances should you clean your ATEX Pressure Meter with a 70% Isopropyl Alcohol Wipe as these can remove the special coating from the LCD Window.

Note - Cleaning should always be conducted outside of the Hazardous Area.

If you are in doubt or need further assistance, please contact Comark or your local Distributor for more information.

Thank you,

Andy

Andrew Wallace

Comark Product Manager

Fluke UK Ltd

Comark Instruments – The Professionals' Choice

Tel: +441604 594254 | Email: andrew.wallace@fluke.com

www.comarkinstruments.com



CELEBRATING
OUR DIAMOND
ANNIVERSARY
1961 - 2021

Contact Comark Direct

E-mail sales@comarkinstruments.com for UK and International Enquiries

E-mail sales@comarkusa.com for USA Enquiries

Comark Instruments
52 Hurricane Way, Norwich, Norfolk, NR6 6JB, UK
Tel: +44 207 942 0712
www.comarkinstruments.com

Comark Instruments
PO Box 500, Beaverton, OR 97077, USA
Tel (503) 643 5204
www.comarkUSA.com

The Professionals' Choice