

P250FW POCKETHERM

WATERPROOF thermometer with fold out probe



Fast, accurate and waterproof thermometer with audible alarm plus flashing LEDs to indicate critical HACCP zones

P250FW Waterproof Pockettherm Folding Thermometer from Comark - it's fast, it folds, it beeps, it's waterproof!

P250FW Pockettherm is fast and accurate - and accurate measurements can mean all the difference between safe and unsafe food, between freshness and spoilage of your products.

Designed for ease of use in the kitchen and other food production areas, the fold out thin tip steel probe (1.5mm) allows the user to select the best angle to take different temperatures.

Features

- Flashing LEDs plus buzzer for instant temperature indication
- Yellow for Hot Hold, Green for Cold Hold and Red for Ground Beef
- Probe can be angled for ergonomic use
- Range: -58°F to +482°F
- Resolution: 0.1°
- Accuracy: ±2°F
- Auto switch off to preserve battery life
- Battery life of more than 1000 hours
- Waterproof to IP65

Change your cooking experience with Pockettherm!



P250FW POKKETHERM WATERPROOF thermometer with fold-out probe



Comark Instruments

P.O. Box 500
Beaverton, OR 97077, USA
Tel: (503) 643 5204
Toll Free: (800) 555 6658
Fax: (503) 627 5311
Email: sales@comarkusa.com

Comark Instruments

52 Hurricane Way
Norwich, Norfolk, NR6 6JB
United Kingdom
Tel: +44 (0) 207 942 0712
Fax: +44 (0) 207 942 0714
Email: sales@comarkinstruments.com



Specifications P250FW

Sensors	Type T Thermocouple
Measurement range	-58°F to +482°F
Scales	°F
Displayed resolution	0.1°
System accuracy (+32°F to +104°F operating)	±2°F
Response time (T ⁹⁹)	5 seconds
Environment	
Operating temperature	-4°F to +122°F
Storage temperature	-22°F to +128°F
Humidity	10 to 90% non-condensing
HACCP Zones P250FW	
Cold Hold (Yellow)	Below +40°F
Hot Hold (Green)	+140°F to +165°F
Ground Beef (Red)	Above +165°F
Power	2 x alkaline AA cells (ANSI 15A IEC LR6)
Battery life	> 1000 hours
Enclosure rating	IP65
Auto switch-off	After 30 minutes

For more information on Comark products, please see www.comarkusa.com

Warranty

All Comark instruments have a minimum one year warranty unless otherwise stated. The warranty for temperature probes is six months and all other probes are unwarranted because the conditions of use are beyond our control. The Comark Warranty covers manufacturing defects and component failure and applies worldwide. In line with our policy of continuous development, we reserve the right to alter any product specification without notice. Comark has an accredited UKAS (NIST equivalent) calibration laboratory for temperature and humidity measurement and offers full service and recalibration facilities.